

To change the main voice mail greetings:

From within your office:

- 1. Press the V-Mail button.
- 2. When the system asks for your password press * # (pound) 0000
- 3. The system will ask for a password: "call us for the password"
- 4. Enter 1 to edit prompts.
- 5. Enter the prompt number:

The OPEN greeting is:

The CLOSED greeting is:

Prompt 1001

Prompt 1002

The HOLIDAY greeting is:

Prompt 1003

The WEATHER greeting is:

Prompt 1004

- 6. Press: 1. To review current recording.
 - 2. DO NOT USE.
 - 3. To delete and re-record.
 - #. To save recording
- 7. Hang-Up

From outside your office:

- $1. \quad 1-xxx-xxx-xxxx$
- 2. When the system asks for your password press # (pound) 0000
- 3. The system will ask for a password: "call us for the password"
- 4. Enter 1 to edit prompts.
- 5. Enter the prompt number:

The OPEN greeting is:

The CLOSED greeting is:

The HOLIDAY greeting is:

Prompt 1001

Prompt 1002

Prompt 1003

The WEATHER greeting is:

Prompt 1004

- 6. Press: 1. To review current recording.
 - 2. DO NOT USE.
 - 3. To delete and re-record.
 - #. To save recording
- 7. Hang-Up



To change the main voice mail mode:

From within your office:

- 1. Press the V-Mail button.
- 2. When the system asks for your password press * # 0000
- 3. The system will ask for a password: "call us for the password"
- 4. Enter 3 to change the mode.
- 5. Enter 0 for all ports.
- 6. Enter the mode number:
 - O. Auto Mode (This will follow the Open/Closed setting on your phone)
 - 1. Open
 - 2. Closed
 - 3. Holiday
 - 4. Weather
- 7. Hang-up.

NOTE- You need to return the voice mail to the AUTO MODE when the office opens for normal business.

From outside your office:

- 1. Call your main telephone number.
- 2. When the system answers press # (pound) 0000
- 3. The system will ask for a password: "call us for the password"
- 4. Enter 3 to change the mode.
- 5. Enter 0 for all ports.
- 6. Enter the mode number:
 - 0. Auto Mode
 - 1. Open
 - 2. Closed
 - 3. Holiday
 - 4. Weather
- 7. Hang-up.
- NOTE- You need to return the voice mail to the AUTO MODE when the office opens for normal business.